

# Important Notice

**Please read the following instructions carefully before using your TV.**

1. This unit requires one time channel setting procedure before using. You can select either Automatic method, which assigns random channel number to the station it catches. Or you can select Manual method, which you can set desired channel numbers to corresponding stations in your local area.
2. You may find the adapter and the TV hotter than other small TVs. However, it is not a sign of defect, rather, it is normal.
3. If you want connect to external Ant. Or Cable for better reception, you need following “F” to “PAL” antenna adapter. (Not Included)



## **Auto Channel Setup**

1. Connect power adapter to the TV.
2. You'll see the red light in front of the TV at the bottom.
3. Press the blue “POWER” button on the main unit.
4. On the remote control, press the red “POWER” button. (Wait 2~3 Sec.)
5. Once the TV is on, Press “SYS” button on the remote control.
6. You need to check the “COLOR” & “SOUND” modes in the display.

|                  |                  |
|------------------|------------------|
| <b>COLOR</b>     | <b>AUTO</b>      |
| <b>SOUND</b>     | <b>M</b>         |
| <b>SELECT</b> ↑↓ | <b>ADJUST</b> ←→ |
7. If the entries are different from above, please adjust them by pressing ← or → button after selecting the menu. If correct, Press “SYS” button to return to channel.
8. Press “MENU” button twice
9. Press “▼” or “▲” button to select “► AUTO MEMORY →”
10. (The color of the selected menu will change from green to red.)
11. Press the “►” button for run the “AUTO CHANNEL MEMORY” on the screen.
12. It will take approximately 10 minutes or more to scan the signal, and assign channel numbers to the available stations randomly.
13. Your TV is now ready.

## Manual Channel Setup:

\* The channel setup must be done manually in order to set channel numbers match the stations in your local area.

It requires about 20 minutes to complete manual channel setup.

1. Connect power adapter.
2. Make sure the red light is on in front of the TV, at the bottom.
3. Press the blue color "POWER" button on the main unit.
4. Press "POWER" button on the remote control. (Wait 2~3 Sec.)
5. Press "SYS" button on the remote control.
6. You need to check the "COLOR" & "SOUND" modes of display.

|                  |                  |
|------------------|------------------|
| <b>COLOR</b>     | <b>AUTO</b>      |
| <b>SOUND</b>     | <b>M</b>         |
| <b>SELECT</b> ↑↓ | <b>ADJUST</b> ←→ |

7. If the entries are different from above, please adjust them by pressing ← or → button after selecting the menu. If correct, Press "SYS" button to return to channel. Press "MENU" button twice
8. Press "▼" or "▲" buttons for the select "POSITION" menu.
9. (The color of the selected menu will change from green to red.)
10. Press "▶" or "◀" button to select the channel number "02" or desired channel number.
11. Press "▼" buttons to select the "BAND" menu.
12. Press "▶" or "◀" button to change and set to "VHFL" (for channels between 2 to 6. For channels between 7 to 13, select VHFH. Over the channels 14, select UHF)
13. Press "▼" button to select the "SKIP" menu.
14. Press "▶" or "◀" button to set it "ON"
15. Press "▼" button to select the "SEARCH" menu.
16. Press "▶" or "◀" button for channel search and find desired station for channel "2"  
(Press, wait and see repeatedly to find desired channel. If displayed screen does not match the desired channel, press "▶" button again.)
17. Once the desired station is up, press the "MEMORY" button several times and select the best picture, and wait a couple of seconds.
18. Press "MENU" button again.
19. Press "▼" or "▲" button to select "POSITION" menu.
20. Press "▶" or "◀" button to select the next desired channel (Ex: CH4 or CH 5).
21. Repeat above number from "15" to "21".

\* Channels 2 ~ 6 : VHFL  
7 ~ 13 : VHFH  
14 ~ 83 : UHF